

GH88 POV Camera Instruction Manual

INTRODUCTION

Thank you for choosing the GH88 POV Camera. This compact and versatile camera is designed for hands-free recording, perfect for capturing your daily life, sports activities, or vlogs from a unique perspective. Its magnetic and clip-on design allows for easy mounting anywhere. This manual provides detailed instructions to help you get the most out of your device.

SAFETY INFORMATION

- Do not expose the camera to extreme temperatures, direct sunlight, or corrosive materials.
- Keep the camera away from water and moisture unless explicitly stated as waterproof.
- Avoid dropping or subjecting the camera to strong impacts.
- Use only the provided USB cable for charging.
- Do not attempt to disassemble or repair the camera yourself. Contact customer support for assistance.
- Ensure proper ventilation during charging.

PACKAGE CONTENTS

- 1 x GH88 Body Camera
- 1 x Magnet Pendant
- 1 x Safety Cord
- 1 x Portable Back Clip
- 1 x USB Cable
- 1 x User Manual (this document)
- (Optional: MicroSD/TF Card, depending on purchase bundle)

Links to Video Tutorials:

GH88 Camera Setup: <https://youtu.be/J3XtNgRMYlw>

GH88 Walking Test: <https://youtu.be/SxyINc72oRo>

GH88 Connect to Phone: https://youtu.be/5H_2MJ0YWc8

GH88 How To Format the SD Card: https://youtu.be/AhVZaKU2_Uc



Figure 1: GH88 Camera and Accessories

PRODUCT OVERVIEW

The GH88 camera features a simple design for ease of use. It includes a central button for operation and an indicator light for status feedback.

Mounting Options:

- **Magnetic Pendant:** Snap the camera onto the magnet pendant for easy POV shots.
- **Portable Back Clip:** Clip the camera to your pocket, belt, cap, or pet's collar. The clip offers 360° adjustable rotation for various angles.
- **Safety Cord:** Use the safety cord with the magnet pendant for dual protection, especially when wearing the camera around your neck.



LIVE PREVIEW & Play Back & Download on App

Mount up the body cam and use App preview your shots and snap away like a pro. (Recommended to use within 32ft (10m))

Figure 2: Mounting Accessories



A truly **no-hands camera**

Go completely hands-free and live in the moment! Set it and forget about it for easy, ultra-wide POV shots.

Figure 3: Magnetic Mounting Example

SETUP

1. Charging the Camera:

Before first use, fully charge the camera. Connect the provided USB cable to the camera's charging port and a USB power source (e.g., computer, wall adapter). The indicator light will show charging status (e.g., solid red while charging, off when fully charged).

2. Inserting a Memory Card:

The GH88 camera supports MicroSD/TF cards. Locate the memory card slot on the camera. Gently insert the MicroSD/TF card with the gold contacts facing down until it clicks into place. Ensure the card is inserted correctly to avoid damage.

3. Connecting to the App (Wi-Fi):

The camera supports Wi-Fi for live preview, playback, and downloading files via a dedicated app (available for iOS and Android). Follow these steps:

1. Download the official app from your device's app store.
2. Power on the camera.
3. Enable Wi-Fi on your smartphone and connect to the camera's Wi-Fi network (SSID and password usually found in the camera's settings or initial setup guide within the app).
4. Open the app to access live preview, manage recordings, and download files.

Note: For the best connection, it is recommended to use the app within 32 feet (10 meters) of the camera in an open environment.

1.27

A small, black, cylindrical camera device is shown floating in the air above an open hand. The device has a lens on the top and a small button on the bottom. The background is a light blue gradient.

0Z

(35.95g)

Small & Lightweight

Tiny camera, huge potential, Mount it and take it anywhere, anytime!

Figure 4: Live Preview via App



Magnet Pendant
Snap on for easy POV shots.



Easy Clip
Clip to your pocket, belt, cap or pet's collar for awesome angles.



Safety Cord
Keep GH88 Safety with Safety Cord.

Figure 5: Instant App Preview and File Management


OPERATING INSTRUCTIONS

Power On/Off:

- **Power On:** Long press the home button on the front of the camera for 3 seconds. The blue LED will turn ON.
- **Power Off:** Long press the home button for 3 seconds. The LED will turn OFF.

Quick Capture (Start/Stop Recording):

- When the camera is ON, simply press the home button once to start recording. The blue LED will FLASH.
- Press the home button once again to stop recording.



Quick Capture

Simply press the home button on the front of the mini camera to start / stop recording instantly, when it's on.

Figure 6: Power and Recording Controls

Hands-Free Recording:

Utilize the magnetic pendant and safety cord or the portable back clip to wear the camera and capture footage without holding it. This allows for immersive, first-person perspective videos.



Figure 7: Hands-Free Recording Examples

Video 1: GH88 Camera Usage Demonstration. This video demonstrates how to wear the camera using the magnetic pendant and how to operate the power and recording functions.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the camera body. For the lens, use a specialized lens cleaning cloth and solution if necessary.
- **Storage:** Store the camera in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the camera frequently. Charge it regularly, even if not in use for extended periods.

TROUBLESHOOTING

- **Camera not turning on:** Ensure the battery is charged. Connect to a power source and try again.
- **Cannot record:** Check if a MicroSD/TF card is inserted and has sufficient free space. Ensure the card is formatted correctly (FAT32 or exFAT).
- **App connection issues:** Make sure the camera's Wi-Fi is enabled and your phone is connected to its network. Ensure you are within the recommended range (10m). Restart both the camera and your phone.
- **Poor video quality:** Ensure the lens is clean and free from smudges. Check lighting conditions.

SPECIFICATIONS

Feature	Detail
Effective MegaPixel	About 2MP
Image Sensor	GPCV1247
Main Processor (Maximum HD Support)	SPCA6330A / M (1080P / 30 FPS)
Image Stabilization	No image stabilization
WIFI Support	Yes
Built-in Mic	Yes
Display Screen	No
NightShot Function	No
Memory Card Type	MicroSD / TF
Body Extension Interface	1/4
Removable/Replaceable Battery	No
Dimensions (L x W x T)	Approx. 2.5 x 1.1 x 0.7 inches (64.5 x 28 x 20 mm)
Weight	Approx. 1.27 oz (35.95g)
Battery Life	Up to 180 minutes (Wi-Fi OFF)
Supporting Language	Japanese, French, German, Italian, Spanish, Portuguese, Russian, English, Swedish, Polish, Greek, Turkish, Korean, Dutch, Latin American Spanish, Brazilian Portuguese, Simplified Chinese, Traditional Chinese Style, Ukrainian

INSTANT APP PREVIEW

Watch immediately After Filming

Download and Sharing Video files on APP.

*Only available on iOS or Android .




Figure 8: Camera Dimensions and Battery Life



1 Power ON

Simply press the home button on the front of the mini camera for 3s to power on . (Blue LED = ON)



2 Quick Capture

Simply press the home button to start / stop recording instantly, when it's on. (Blue LED = FLASH)



3 Power off

Simply press the home button on the front of the mini camera for 3s to power off . (LED = OFF)

Figure 9: Camera Weight

USER TIPS

- **Battery Life:** To maximize recording time, especially during long sessions, consider turning off Wi-Fi when not actively using the app for live preview or file transfer. The camera offers up to 180 minutes of recording with Wi-Fi off.
- **Non-Replaceable Battery:** Please note that the camera's battery is not designed to be user-removable or replaceable. Proper charging habits will help maintain its lifespan.
- **Mounting Versatility:** Experiment with different mounting options (magnetic pendant, back clip) to find the best angle for your specific activity. The 360° rotating clip is particularly useful for adjusting the view on the fly.

WARRANTY AND SUPPORT

For warranty information, technical support, or any questions not covered in this manual, please contact the seller or refer to the product listing page for contact details. Keep your purchase receipt as proof of purchase.



GH88 POV Camera Demonstration: Wearable Body Camera for Hands-Free Recording